Red is ready to use status. Amber means that its in program mode.

red

You must press E after every mastercode.